

# I Adhesive Recommendation

## Luxury Vinyl Tile

### Tarkett I



#### Substrate Preparation

Substrates (for example)	Gypsum based substrates	Concrete / Cement based substrates	Prefabricated boards (OSB, particle board)
Primer (for example)	SCHÖNOX KH FIX ( EC1 PLUS)	SCHÖNOX VD (EC1 PLUS)	
Self Leveling Compound (for example)	SCHÖNOX AP (EC1 PLUS) SCHÖNOX ZM (EC1 PLUS R) SCHÖNOX US (EC1 PLUS R)		

#### Floor Covering Installation

Floor covering	iD Essential 30, iD Selection 40, iD Inspiration 70, iD Inspiration 55		
Loading	Residential / Commercial		Heavy Loadings (e. g. display windows, conservatory, wet rooms)
Recommended Adhesive	SCHÖNOX ROLL AND GO® Rollable Acrylic Adhesive for Luxury Vinyl Tiles (EC 1)	SCHÖNOX EMICLASSIC™ Universal Pressure Sensitive Acrylic Adhesive for all Flexible Coverings (EC1 PLUS)	SCHÖNOX PU 900 2-Component Universal Polyurethane Adhesive ( EC 1 PLUS R )
Tool	SCHÖNOX ROLL AND GO ROLLER	Notched trowel 1/16" x 1/16" x 1/16"	Notched trowel 1/8" x 1/8" x 1/16"
Coverage	approx. 540 sq. ft. per Set (containing adhesive, primer and the required tools)	approx. 500 - 700 sq. ft. per unit of 3.35 gal.	approx. 105 sq. ft. per unit of 1.09 gal.

The requirements of the relevant valid standards, guidelines and data sheets apply. Do not install underlayment or topping before the substrate has dried thoroughly. Follow the technical product information of the floor coverings manufacturers regarding specific substrate requirements for their coverings. If in doubt we recommend to test in a small area.

