

# SCHÖNOX ROLL AND GO™ STAND UP FOR THE BEST WAY TO INSTALL LUXURY VINYL TILE.



## ROLLABLE ACRYLIC ADHESIVE

Roll and Go™ comes in an integrated kit containing everything you need to prepare a floor for LVT. Roll and Go™ can be applied from a standing position, resulting in a faster, cleaner, easier job for the installer.

© 2024\_HPS\_ROLL AND GO\_SELL SHEET\_HPS-2428

# SCHÖNOX ROLL AND GO™

## FOR RESIDENTIAL AND COMMERCIAL INSTALLATIONS

Floor installation can begin 15 minutes after application. Tiles are bound immediately and can bear loads right away.



CASTOR WHEEL LOADING



MARINE APPLICATION



INTERIOR ONLY



GEV-EMICODE

### PRODUCT CHARACTERISTICS

- EMICODE EC1: very low emission
- For interior use only
- Solvent-free
- Long open time
- High coverage - approx. 540 sq.ft. per 1.06 gal. unit (part of the Schönnox Roll and Go™ kit) - approx. 1,380 sq.ft. per 2.7 gal. unit
- To be applied with Schönnox Roll and Go™ roller
- Standing application
- Easy to apply
- Low odor
- Can take immediate loading
- Suitable on underfloor heating systems
- Suitable on all Schönnox floor leveling compounds, preferably with synthetic gypsum self-leveler Schönnox AP or Schönnox AP Rapid
- Conforms with MED 96/98/EC

### RECOMMENDED APPLICATION DETAILS

- Review substrate requirements in detail at [hpsubfloors.com](http://hpsubfloors.com)
- Schönnox Roll and Go™ is stirred before use.
- Coverings to be bonded with Schönnox Roll and Go™ should be acclimated in a flat position for 48 hours before installation.
- Schönnox KH Fix primer should be applied to substrate using KH Fix roller, supplied in kit.
- Evenly apply Schönnox Roll and Go™ with the Schönnox Roll and Go™ roller onto the substrate, avoiding pools of adhesive.
- After fitting the LVT without any bubbles, roll the flooring using a metal roller. A second rolling should be done at the end of the project.
- Trafficking, loading and polishing of coverings bonded with Schönnox Roll and Go™ can be done immediately.
- The replacement of planks/tiles is possible without further substrate preparation using Schönnox Roll and Go™. Replacements are done using the contact method, first applying Schönnox Roll and Go™ on the backing of the new LVT.

After drying to transparency, press the covering to the substrate covered with Schönnox Roll and Go™.

- Use soapy water to remove fresh adhesive spots. Dried spots can be cleaned with Schönnox Fix Clean.
- Contact us for further information. Obtain and review product technical data sheets before starting any project.



### LEED V4.1 ID+C, BD+C

Contributes to LEED v4.1 certification of projects in these categories:

- EQc2 – 3 points Low-Emitting Materials
- MRc1 – up to 2 points Life-Cycle Impact Reduction
- MRc2 – 1 point Environmental Product Declaration
- MRc4 – 1 point Material Ingredient
- Environmental Product Declaration (EPD) Declaration number: EPD-DBC-20220146-IBF1-EN
- 0g/l (calculated) SCAQMD 1168



1. Start with a smooth, sound subfloor. Don't have that? Use Schönnox AP, synthetic gypsum self-leveling compound, as shown here.



2. Open the fully integrated Roll and Go™ package.



3. Roll on Schönnox KH Fix universal primer.



4. Roll on the adhesive.



5. Install LVT.

\*Refer to Technical Data Sheets for additional, current information. Available on the Schönnox App and [hpsubfloors.com](http://hpsubfloors.com).

Take your business to a whole new level. Call 855.391.2649 or visit [hpsubfloors.com](http://hpsubfloors.com) to learn how your projects run smoother with Schönnox On It.



**SCHÖNOX**<sup>®</sup>  
HPS NORTH AMERICA